



Operating Room Cleaning TERMINAL, CHECKLIST



Name: _____
Room: _____
Time: _____
Date: _____

Preparation and Set Up:

- ☐ Prepare equipment and load cleaning cart with everything needed for the job
- ☐ Prepare yourself by dressing in the appropriate attire and personal protective equipment (PPE)

Cleaning Process:

- ☐ Remove all soiled linen
- ☐ Remove medical waste & reline containers
- ☐ Pick up trash and large debris with Lobby Pro Wet/Dry Dust Pan and Lobby Pro Wand
- ☐ Remove all other waste & reline containers
- ☐ Dry/damp dust all booms and attachment points for lights and equipment suspended from the ceiling with Flexible Wand and Extension Handle

Cleaning Process:

- ☐ Dry/damp dust on top of all cabinets and shelving with the Flexible Wand or Flexi Frame and Extension handle
- ☐ Clean overhead light with Green Rubbermaid HYGEN™ microfiber cloth
- ☐ Thoroughly clean OR Table with Red Rubbermaid HYGEN™ microfiber cloth and a disinfectant
- ☐ Clean Mayo Stands and tray tables with a Green Rubbermaid HYGEN™ microfiber cloth and a disinfectant approved by your supervisor
- ☐ Damp clean entire ceiling with 18" Rubbermaid HYGEN™ Damp Mop on extension handle using Charging Bucket
- ☐ Damp clean all walls with 18" Rubbermaid HYGEN™ Damp Mop on extension handle using Charging Bucket
- ☐ Move all OR equipment and tables to one side of the room and clean floors with an auto scrubber
- ☐ Wipe down casters on all tables and equipment with Green HYGEN™ microfiber cloth
- ☐ Move all OR equipment and tables to opposite side of room and clean floor, rolling casters in disinfectant solution on the floor
- ☐ Return all tables and equipment to their original positions
- ☐ Inspect cleaning & review checklist
- ☐ Remove personal protective equipment (PPE) and thoroughly wash hands, being careful to avoid self contamination

NOTE: This Checklist is a recommendation of best practices within the industry. We also recommend referencing AORN's Perioperative Standards and Recommended Practices and OSHA Guidelines. Always use the cleaning chemical(s) specified by your supervisor and follow the chemical manufacturers use directions.

The AORN Seal of Recognition has been awarded to Rubbermaid HYGEN™ and does not imply that AORN approves or endorses any product or service mentioned in any presentation, format or content. The AORN Recognition program is separate from the AORN, ANCC Accredited Provider Unit and therefore does not include any CE credit for programs.

